



PART NUMBER
PFF5-1401

DESCRIPTION
FRONT RADIUS ARM TO CHASSIS BUSH

INSTALLATION GUIDE

Contents (parts per pack):

4 x Polyurethane bushes
2 x Stainless steel sleeves
1 x Grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original rubber bush from the arm, clean any dirt and corrosion from the bore in the arm. Using a file remove any sharp edges from around the bore of the arm creating a small chamfer.
2. Insert one polyurethane bush into bore of the arm, aligning the arrow on the bush with the arrow on the arm. This ensures correct alignment of the voided sections of the bush. Insert the other half of the polyurethane bush into the other side of the arm, again aligning the arrow on the bush with the arrow on the arm.
3. Apply some of the supplied grease to the bore of the bush and insert the stainless steel sleeve into the bush.
4. Re-fit the arm to the car and tighten all hardware to manufacturers recommended torque settings.

