



PART NUMBER

PFF5-4101

DESCRIPTION

FRONT CONTROL ARM TO CHASSIS BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane bushes
- 2 x Stainless steel sleeves
- 1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove original bush from arm.
2. Clean any dirt and corrosion from bore in arm, removing any sharp edges around bore.
3. Fit the polyurethane bush into arm.
4. Fit steel washer on stainless steel sleeve.
5. Apply supplied grease in and around bore of polyurethane bushes.
6. Insert stainless steel sleeve into bush with bore positioned closest to centre of vehicle, as shown in *Figure 1*.
7. Ref t arm. Tension all hardware to manufacturers recommended torque settings.

Figure 1: Fitted Assembly

